

## Function Description

Addr	A001-A512	512 Address setting
CHnd	12CH	12 channel setting
	10CH	10 channel setting
SLnd	Auto	Host mode
	SL 1	Console mode
	SL 2	Secondary mode
SHnd	SH 0	Effect 0 (recommended)
	SH 1	Effect 1
	SH 2	Effect 2
	SH 3	Effect 3
Soud	on	Voice activated
	oFF	Voice off
SEnS	0-99	Voice-activated sensitivity adjustment
bLnd	bLAc	No 512 signal return to zero
	Auto	No 512 signal self-propelled
	Soun	No 512 signal sound
	HoLd	No 512 signal keeps last console state
LEd	OFF	After 5 seconds off the screen
	ON	The screen is always on
dISP	no	Display reverse
	YES	Display positive
rPAN	no	X motor forward
	YES	X motor reversal
rTiL	no	Y motor forward
REST	YES	System reset

## 12 Channel

Channel	Features	Instructions
1	Horizontal operation	0-255
2	Horizontal fine-tune	0-255
3	Vertical operation	0-255
4	Vertical fine-tune	0-255
5	color	
	0-139	Color selection
	140-255	Automatic color change from slow to fast
6	Gobo	
	0-63	Fixed gobo
	64-127	Shaking gobo
	128-255	Automatic change pattern from slow to fast
7	strobe	0-255
8	Dimming	0-255
9	Motor speed	0-255 from fast to slow
10	Automatic mode	
	0-59	Other channels function
	60-84	Automatic mode3
	85-109	Automatic mode2
	110-134	Automatic mode1
	135-159	Automatic mode0
	160-184	Voice-control mode3
	185-209	Voice-control mode2



	210-234	Voice-control model
	235-255	Voice-control mode0
11	reset	250-255 (5 秒) 5 Seconds
12	Light strips	5-109 Color selection 110-255 Color auto operation

## 10 Channel

channel	Features	Instructions
1	Horizontal operation	0-255
2	Vertical operation	0-255
3	color	
	0-139	Color selection
	140-255	Automatic color change from slow to fast
4	Gobo	
	0-63	Fixed gobo
	64-127	Shaking gobo
	128-255	Automatic change pattern from slow to fast
5	strobe	0-255
6	Dimming	0-255
7	Motor speed	0-255
8	Automatic mode	0-255 Adjust forward rotation upwards and downward rotation backwards
9	Reset	250-255 (5 seconds)
10	Light strips	5-109 Color selection 110-255 Color auto operation

	210-234	Voice-control mode1
	235-255	Voice-control mode0
11	reset	250-255 (5秒)
12	Light strips	5-109 Color selection 110-255 Color auto operation

## 10 Channel

channel	Features	Instructions
1	Horizontal operation	0-255
2	Vertical operation	0-255
3	color	
	0-139	Color selection
	140-255	Automatic color change from slow to fast
4	Gobo	
	0-63	Fixed gobo
	64-127	Shaking gobo
	128-255	Automatic change pattern from slow to fast
5	strobe	0-255
6	Dimming	0-255
7	Motor speed	0-255
8	Automatic mode	0-255 Adjust forward rotation upwards and downward rotation backwards
9	Reset	250-255 (5 seconds)
10	Light strips	5-109 Color selection 110-255 Color auto operation