

11Channel Mode:

| Channel | Function | Description | color |
|----------|---|----------------|-----------------------------------|
| 5 | Choose color | 0-9 | white |
| | | 10-19 | red |
| | | 20-29 | yellow |
| | | 30-39 | blue |
| | | 40-49 | green |
| | | 50-59 | orange |
| | | 60-69 | pink |
| | | 70-79 | light blue |
| | | 80-89 | Pink and light blue |
| | | 90-99 | pink and orange |
| | | 100-109 | orange and green |
| | | 110-119 | blue and green |
| | | 120-129 | yellow and blue |
| | | 130-139 | red and yellow |
| | change the color autotomatically | 140-255 | from slow to fast |
| 6 | Fixed Godo | 0-7 | Figure 1 |
| | | 8-14 | Figure 2 |
| | | 15-23 | Figure 3 |
| | | 24-31 | Figure 4 |
| | | 32-39 | Figure 5 |
| | | 40-47 | Figure 6 |
| | | 48-55 | Figure 7 |
| | | 56-63 | Figure 8 |
| | Pattern dither | 64-71 | Figure 1 form slow to fast |
| | | 72-79 | Figure 2 form slow to fast |
| | | 80-87 | Figure 3 form slow to fast |
| | | 88-95 | Figure 4 form slow to fast |
| | | 96-103 | Figure 5 form slow to fast |
| | | 104-111 | Figure 6 form slow to fast |
| | | 112-119 | Figure 7 form slow to fast |
| | | 120-127 | Figure 8 form slow to fast |

