

## Technical parameters:

Voltage: AC100-240V, 50/60Hz

Power: 150W

Light source: 30W\*40pcs RGB 3IN1 LED+48pcs SMD5050 LED

Control mode: DMX512,sound,auto,master-slave

Effect: Pixel control,led and SMD can be controlled separately

Raw material: Aluminum + Plastic

Package: 10pcs in a master box

Inner box: 29\*10\*27 cm

Master box: 53\*30\*55.5cm

Weight: N.W:11.1KGG.W: 16.4KG

## LED stage lighting equipment usage manual

# 4 eyes COB Blind lamp



Please read the instructions carefully before using them

### 1. Digital tube display menu description:

Order numbr	content	scale	Function and description
1	A001	001- 512	DMX512Address code setting
2	10CH	06/10/19	DMXChannel mode setting
3	Au01	1 - 12	Preset effect,12Sound control effect
4	SP16	00 - 16	Preset effect change speed setting , From slow to fast.
5	St00	00 - 20	Stroboscopic effect, 1-20The speed is slow to fast .
6	R255	000 - 255	3in1Red tone light , From dark to bright.
7	G255	000 - 255	3in1Green tone light , From dark to bright.
8	B255	000 - 255	3in1Blue tone light , From dark to bright.

### 2、DMX channel menu

#### 6 channel mode

chann el	function	explain
CH1	000-255	COB RRed tone light, From dark to bright
CH2	000-255	COB GGreen tone light, From dark to bright
CH3	000-255	COB BBlue tone light, From dark to bright
CH4	000-255	3in1 Light with R red hue, From dark to bright
CH5	000-255	3in1 Light with G green hue, From dark to bright
CH6	000-255	3in1 Light with B blue tone, From dark to bright

#### 10channel mode

channel	function	explain
CH1	000-255	Total dimming, Total dimming
CH2	005-255	Total stroboscopic, From slow to fast
CH3	000-005	all-or-none
	006-255	Preset effect selection
CH4	000-255	Preset effect speed, From slow to fast
CH5	000-255	COB RRed tone light, From dark to bright
CH6	000-255	COB GGreen tone light, From dark to bright
CH7	000-255	COB BBlue tone light, From dark to bright
CH8	000-255	3in1 Light with R red hue, From dark to bright
CH9	000-255	3in1 Light with G green hue, From dark to bright
CH10	000-255	3in1 Light with B blue tone, From dark to bright

#### 19 channel mode

channel	function	explain
CH1	000-255	Total dimming, from dark to bright
CH2	005-255	Total strobe, from slow to fast
CH3	000-005	none
	006-255	Preset effect selection
CH4	000-255	Preset effect speed, from slow to fast
CH5	000-255	1# COB RRed tone light, From dark to bright
CH6	000-255	1# COB GGreen light, from dark to bright
CH7	000-255	1# COB BBlue dimming , from dark to bright
...	.....	.....
CH14	000-255	4# COB RRed light, from dark to bright
CH15	000-255	4# COB GGreen light, from dark to bright
CH16	000-255	4# COB BBlue dimming , from dark to bright
CH17	000-255	3in1 Light with R red hue, from dark to bright
CH18	000-255	3in1 Light with G green hue, from dark to bright
CH19	000-255	3in1 Light with B blue light, from dark to bright