

Led small airship

User Manual

Thank you for purchasing led small airship, for your personal safety and better use of the product, be grateful you read this manual carefully before use, according to operating procedures to avoid misuse caused the damage to personal safety and lighting.

- **Package list:**

When you unpack the case , please take time to examine the items as follow:

.....Projector 1

.....Owner`s manual 1

- **Technical Parameters:**

Work voltage: AC90 - 240V, 50 - 60 Hz

Power:10W

Light source: 64 pcs 5mm LEDs (R4,G28,B20,W12)

Control mode: music control, automatic

Operating Environment: indoor

- **Instructions for use:**

After opening the box, carefully check whether the LED light damage due to transportation, such as the screw is loosen and so on.

Please check before applying power. Check the lighting placement is correct and secure, check the power supply electrical pressure is the same with this product, or damage to the lamp is not an example of warranty. Examination was normal after the use of electricity.

- **Control mode set up detail as bellow:**

No.	Control mode	Control switch (ON)
1	single projector controlled by sound	9 is on,the rest OFF
2	single projector automatically run	1-10:OFF
3	Speed control	8-1:ON

Note: This light must be good power supply connection,if the light crashes,please use the light after 10 seconds .

- **Maintenance:**

It is very important to keep the light clean, therefore please clean reflector lens monthly to keep the lights away from dust, dirt or fog juice. We suggest that clean the light with professional glass cleaning lotion and downy cloth. Keep the light. Clean regularly will not only maintain the maximum laser output brightness but also will extend the life span of the laser.